


# **OPERATING INSTRUCTIONS**

# CASTER SYSTEM



CASTER SYSTEM 112110, 112115, 112120, 112125, 112135, 112140, 112145, 112150, 112155

VERSION 1 JANUARY 2021 © 2021

# COMPANY INFORMATION

90 GRAD GmbH

Managing Director: Mario Riegger

Cell phone +49 173 8936494
E-mail mr@90grad.net
Website www.90grad.net

Address Tobelweg 26 A, 88090 Immenstaad am Bodensee, Germany

#### CASTER SYSTEM

The caster system from 90 GRAD GmbH has retractable swivel casters in the feet, giving you a simple, convenient way to move furniture, work tables, and machine tables. The feet can be installed in hollow sections such as table legs, and in base plates on furniture.

An anti-slip rubber coating on the bottom of the feet ensures the furniture is kept securely in place.

#### NOTE

Observe the maximum pressure load for the caster system.


Please see the technical data: "Load capacity".

#### TECHNICAL DATA

#### **CASTER SYSTEM** Shaft diameter (a) 46 mm (max. 47.5 mm) Shaft length (b) 84 mm Support ring height (c) 5 mm Support ring diameter (d) 50 mm Adjustment range 16 mm 1.5 mm **Increments** Weight without caster and axle 94 g **Load capacity** 50 kg Plate thickness (e) 6 mm (if installed in base plates) Material Glass fiber reinforced plastic Color Black (standard) Choice of colors on request Caster Swivels 360°

# TECHNICAL DATA

CASTER SYSTEM									
Article	Caster								
number	Diameter	Width	Surface	Color	Axle length	Axle position			
112110	15 mm	13 mm	Hard	White	24 - 28 mm	Type C 9.2 mm off-center			
112115	15 mm	13 mm	Soft	Gray	24 - 28 mm				
112120	16 mm	15 mm	Hard	Black	24 - 28 mm				
112125	16 mm	15 mm	Soft	Gray	24 - 28 mm				
112135	20 mm	12 mm	Soft	Gray	26 - 28 mm	Type A 8 mm off-center			
112140	25 mm	15 mm	Hard	Black	26 - 32 mm	Type B			
112145	25 mm	15 mm	Soft	Gray	26 - 32 mm	center			
112150	27 mm	13 mm	Hard	White	26 - 32 mm				
112155	27 mm	13 mm	Soft	Grav	26 - 32 mm				



#### INSTALLATION PROCESS FOR HOLLOW SECTIONS

The installation process is shown using the example of a table leg.


#### **⚠** CAUTION



#### Risk of crushing

There is a risk of crushing fingers and hands when installing the feet.

 Ensure that the table is held securely when it is raised.



#### **INSTALLATION PROCESS FOR BASE PLATES**

#### **⚠** CAUTION



#### Risk of crushing

There is a risk of crushing fingers and hands when installing the feet.

 Ensure that the item of furniture is held securely when it is raised.



➤ Drill a hole with a diameter of 46.5 mm nto the base plate.



► Push the foot into the base plate as far as it will go.

#### **NOTE**

The feet are guaranteed to be held securely in the base plate if the base plate is max. 6 mm thick.

The spring hooks on the feet prevent the feet falling out of the base plate when lifting the item of furniture. If the base plate is thicker, the feet will merely be pressed against the wall of the base plate.

# REPLACING THE CASTERS




▶ Lever the caster plus its axle out of the slot.



► Insert the axle into the caster and press it into the relevant slot (please see the technical data: "Caster").

# **EXTENDING THE CASTERS**

The process of extending the casters is shown using a table by way of example.




- ► Lift the table approx. 1 cm on one side and let it go.
- ► Lift the table approx. 1 cm on the opposite side and let it go.

#### NOTE

The casters have been extended. The table can now be moved.

# RETRACTING THE CASTERS

The process of retracting the casters is shown using a table by way of example.



- ► Lift the table fully off the floor on one side and set it down again.
- ► Lift the table fully off the floor on the opposite side and set it down again.

#### **NOTE**

The casters have been retracted.



# 90 GRAD GmbH

CONTACT DETAILS

CELL PHONE +49 173 8936494
E-MAIL MR@90GRAD.NET
WEBSITE WWW.90GRAD.NET

ADDRESS TOBELWEG 26 A, 88090 IMMENSTAAD AM BODENSEE, GERMANY